

Evolutionary Calibrators

Accurate • Rugged • Reliable • Easy to Use Troubleshoot Loops - Automatic Diagnostics World Wide Support - Made in USA

Practical Instrument Electronics

* Webster, NY 14580 USA Tel: 585.872.9350 * Fax: 585.872.2638 sales@piecal.com * www.piecal.com

Milliamp Loop Diagnostic Calibrators

PIECAL Model 334 - Just Like an Old Friend

- Calibrate Milliamp Instruments
 Source 0.00 to 24.00 mA & -25.0 to 125.0% of 4-20 mA; Read 0.00 to 52.00 mA, -99.99 to 99.99 V
 Simulate 2-Wire Transmitters; Power & Read 2-Wire Transmitters
- Calibrate with Confidence Accurate to ±0.025% of Span at 4.000 & 20.000 EZ-CHECK outputs
- Use in the Plant, Field or Shop Includes Rubber Boot and Attached Test Leads; Low profile switches resist accidental damage
- Simple Battery Changes
 Separate compartment for no-tool battery changes with four inexpensive "AA" batteries
- Optional Accessories
 AC Adaptor 120 V (020-0101); 240 V (020-0100); NiMh Batteries & Charger 120 VAC/12V DC (020-0103)
 Improvements over 334s from other manufacturers include better long term stability, accuracy, reliability & ruggedness plus improved battery life. PIECAL 334 is the perfect replacement for your worn out mA calibrators!



Do More with the Evolutionary PIECAL 434! 10-50 mA for Nuclear Power Plants with PIECAL 1040!

- Calibrate Milliamp Instruments PIECAL 434: Source & Read 0.000 to 24.000 mA & -25.00 to 125.00% of 4-20 mA; PIECAL 1040: Source and Read 0.000 to 52.000 mA & -25.00 to 125.00% of 4-20mA & 10-50mA Read -99.99 to 99.99 V; Simulate 2-Wire Transmitters, Power & Read Transmitters Menu Selectable 250 Ω resistor for HART compatibility
- Calibrate with Confidence Accurate to ±0.025% of Span at 4 & 20 EZ-CHECK outputs
- Easy-to-Read Backlit Display Includes Rubber Boot and Attached Test Leads
- Locate Loop Current Leakages Automatic indication of Loop Current and Leakage Current. Measure ground current leakage from faulty wiring, flooded conduit and corrosion bridges. Leakage appears as a Zero Shift and helps you decide if the transmitter needs calibration or if there is a problem in the loop wiring.
- Faster Calibrations Three output EZ-CHECK switch. 2 speed EZ-DIAL; Stepping & Ramping
- Optional Accessories AC Adaptor 120 V (020-0101); 240 V (020-0100)
 NiMh Batteries & Charger 120 VAC/12V DC (020-0103)



Calibrate & Troubleshoot Loop Problems with the Model 532

- Calibrate Milliamp & Voltage Instruments Source to 24.000 mA & 24.000 Volts DC; Read 0.000 to 24.000 mA, 0.000 to 24.000 V, 24.01 to 30.00 V Simulate 2-Wire Transmitters, Power & Read 2-Wire Transmitters; 250 Ω resistor - HART compatibility
- Calibrate with Confidence

 Current: Accurate to ±(0.012% of Reading + 0.002 mA); Voltage: Accurate to ±(0.012% of Reading + 0.004 V)
- Troubleshoot Loops & Find Ground Faults
 Patented loop diagnostics take dynamic loop readings under operating conditions. Automatic indication of Loop Current, DC Voltage, Resistance and Leakage Current. Displays AC Voltage & presence of HART.
- Locate Loop Current Leakages Find ground current leakage faulty wiring, flooded conduits & corrosion bridges.
- Faster Calibrations Select 3 outputs with EZ-CHECK switch. 2 speed EZ-DIAL plus Stepping & Ramping
- Includes Attached Test Leads & Carrying Case (020-0204)
- Optional Accessories AC Adaptor for 120 VAC (020-0101); AC Adaptor for 240 VAC (020-0100)



Evolutionary PIECAL 134 - Small Size, Big Performance

- Calibrate Milliamp Instruments Source & Read 0.00 to 24.00 mA & -25.00 to 125.0% of 4-20 mA; Simulate 2-Wire Transmitters Power & Read 2-Wire Transmitters; Selectable 250 Ω resistor for HART compatibility
- Calibrate with Confidence Accurate to ±(0.05% of Reading + 0.01 mA)
- Compact & Affordable Pocket sized with built-in belt clip & attached test leads
- Faster Calibrations Instantly select three outputs with EZ-CHECK switch & two speed EZ-DIAL knob
- Optional Accessories Carrying case with belt clip (020-0200)



High Accuracy T/C & RTD Calibrators

Evolutionary PIECAL 322-I & 422 Automated T/C Calibrators

- PIECAL 422 Source and Read Fourteen T/C Types plus mV
 J, K, T, E, R, S, B, N, G, C, D, L (J DIN), U (T DIN) & P (Platinel); -13.000 to 80.000 mV
- PIECAL 322-1 Source and Read Four T/C Types plus mV
 I, K,T, & E; -13.000 to 80.000 mV
- Calibrate with Confidence Resolution of 0.1° F & C; Accurate to 0.2°
- Faster Calibrations Instantly select three outputs with EZ-CHECK switch Easily find trip points with two speed EZ-DIAL & Automatic Stepping.
- Easily Change T/C Types & Scale Double click to select T/C type & °F & C
- Easy-to-Read Display Turn on the backlight to read in dark areas of the plant
- Use in the Plant, Field or Shop Includes Rubber Boot and mV Test Leads Low profile switches resist accidental damage
- Simple "No Tool" Battery Changes 4 inexpensive "AA" batteries
- Verify Cold Junction Temperature & Output (422 Only)
 Secondary display of compensated millivolt setting and cold junction temperature
- Optional Accessories
 Wire & Mini T/C Plug: J, T, E, K (020-0202); B, R/S, K (020-0203)



Evolutionary PIECAL 211 & 311 Automated RTD Calibrators

- Calibrate with Precision Resolution to 0.01° F & C; Accurate to 0.2°
- Source and Read Multiple RTD Curves plus Ohms Platinum 100 Ω : α =1.3850, 1.3902, 1.3926; Platinum 1000 Ω : α =1.3850, 1.3750 Copper 10 & 50 Ω ; Nickel 110 & 120 Ω ; 0.00 to 4010.0 Ω (PIECAL 211 0.00 to 2010.0 Ω)
- Automatically Detect 2, 3 & 4 Wire Connections
 Troubleshoot sensor connections & find broken wires with patented technology
- Guaranteed Compatible with all Instrumentation
 Works with Rosemount & Honeywell Smart Transmitters, PLCs, DCSs, Multi-Channel Recorders and other pulsed excitation devices
- Faster Calibrations Instantly select three outputs with EZ-CHECK switch Easily find trip points with two speed EZ-DIAL knob & Automatic Stepping
- Easily Change RTD Types & Scale Double click to select RTD & °F & C
- Verify RTD Temperature & Output (311 Only) Secondary display of Ohms
- Easy-to-Read Display Turn on the backlight to read in dark areas of the plant
- Simple "No Tool" Battery Changes 4 inexpensive "AA" batteries
- Use in the Plant, Field or Shop Includes Rubber Boot and RTD Wire Kit (020-0208)



High Resolution & Accuracy 525 Thermocouple & RTD Calibrator

- Calibrate with Precision High resolution to 0.1° and 0.01° F & C; Accurate to 0.2°
- Source and Read Multiple Thermocouple Types plus mV
 J, K, T, E, R, S, N and B; -13.000 to 80.000 mV
- Source and Read Multiple RTD Curves plus Ohms Platinum 100Ω : α =1.3850, 1.3902, 1.3926; Copper 10 & 50Ω ; Nickel 110 & 120Ω ; 0.000 to 400.000 Ohms
- Automatically Detect 2, 3 & 4 Wire Connections
 Troubleshoot sensor connections & find broken wires with patented technology
- Guaranteed Compatible with all Instrumentation
 Works with Rosemount & Honeywell Smart Transmitters, PLCs, DCSs, Multi-Channel Recorders and other pulsed excitation devices
- Faster Calibrations Instantly select 3 outputs with EZ-CHECK switch; 2 speed EZ-DIAL; Auto Stepping
- Includes Carrying Case (020-0205) and RTD Wire Kit (020-0206)
- Optional Accessories Wire & Mini T/C Plug: J,T, E, K (020-0202); B, R/S, K (020-0203)



T/C & RTD Calibrators / Frequency Calibrator

Thermocouple Calibrator

Model 522

- Source and Read Multiple Thermocouple Types plus mV
 J, K, T, E, R, S, N and B; -13.000 to 80.000 mV
- Calibrate with Confidence Resolution of 0.1° F & C;Accurate to 0.2°
- Faster Calibrations
 Instantly select three outputs with EZ-CHECK switch
 Easily find trip points with two speed EZ-DIAL & Automatic Stepping
- Optional Accessories for 522, 521 & 520
 Carrying case (020-0205)
 Wire & Mini T/C Plug Types J, T, E, K (020-0202)
 Wire & Mini T/C Plug Types B, R/S, K (020-0203)



Model 521 (not pictured)

 Source Only - Multiple Thermocouple Types plus mV Same ranges as Model 522

Model 520 (not pictured)

Source Only - One T/C Type

RTD Calibrator

Model 512

- Source and Read Multiple RTD Curves plus Ohms Platinum 100 Ω : α =1.385, 1.3902, 1.3926 Copper 10 & 50 Ω ; Nickel 110 & 120 Ω ; 0.000 to 400.000 Ohms
- Calibrate with Confidence Resolution of 0.1° F & C:Accurate to 0.2°
- Faster Calibrations
 Instantly select three outputs with EZ-CHECK switch
 Easily find trip points with two speed EZ-DIAL knob
 Automatic Stepping with selectable step size (Model 512S)
- Includes Attached Test Leads
- Optional Accessories for 512, 511 & 510: Carrying case (020-0205)



Model 511 (not pictured)

 Source Only - Multiple RTD Curves plus Ohms
 Same ranges as Model 512

Model 510 (not pictured)

 Source Only - One RTD Curve

Frequency Calibrator

- Calibrate Flow Meters and Frequency Instruments
 Generate Sine Waves, Zero based & Zero crossing Square Waves; Adjust amplitude from 100 mV-12V p-to-p
- Read with Built-in Frequency counter Measures waveforms from 0.1V-120V peak-to-peak
- Calibrate with confidence Accurate to ±0.005% of Range
- Compatible with Process Signal Ranges
 0.001 kHz to 20.000 kHz; 0.1 Hz to 2000.0 Hz; 0.01 Hz to 200.00 Hz
 0.1 CPM (Counts-per-minute) to 2000.0 CPM; I CPH (Counts-per-hour) to 20000 CPH
- Calibrate Totalizers Totalize Inputs/Outputs from 1 to 99999 counts in 0.1 to 100.0 minutes
- Includes Attached Leads & Carrying Case
- Optional Accessories AC Adaptor for 120 VAC (020-0101); AC Adaptor for 240 VAC (020-0100)





PIECAL Calibrators are designed and built by members of the same team that designed and built the calibrators manufactured by Fluke* under the Altek* label.

Practical Instrument Electronics
841 Holt Road #1 • Webster, NY 14580 USA
Tel: 585.872.9350 • Fax: 585.872.2638
sales@piecal.com • www.piecal.com

* PIECAL Calibrators are not manufactured or distributed by Fluke Corp. or Altek Industries Inc, manufacturers of Altek Calibrators.